

# 22.08 KW Type2 Wall Mounted Charging Stations EV Charger Wallbox Electric Vehicle Charging Station

# **Basic Information**

Place of Origin: China
Brand Name: MINKO
Certification: CE, ROHS
Model Number: Wallbox-M22
Minimum Order Quantity: 5 pieces
Price: negotiation

Packaging Details: L210xW85xH52 (mm)
 Delivery Time: 8 -10 working days
 Payment Terms: T/T, Western Union,

MoneyGram,Paypal,Skrill,Transferwise

• Supply Ability: 1000000 pieces per month



# **Product Specification**

• Charging Plug: Type 2(Mennekes)

Withstand Voltage: 3000v

• Input / Output Current: 8,12,16,20,24,28,32A Adjustable

Max Output Power: 22.08 KW
Output Cable: 5M
Work Altitude: <2000M</li>
Stand By: <3W</li>
IP Level: IP65

• Highlight: 22kw ev wallbox charger,

ip65 wall mounted ev charger, type2 wall mounted ev charger



# More Images



#### **Product Description**

#### 22.08 KW Type2 Wall-mounted Charging Stations EV charger Wallbox Electric Vehicle Charging Station

#### **Description of Type2 Wallbox EV Charger**

This product is mainly composed of charging station host, charging gun, wire, installation backplane, installation ingredients package, etc. It is a household electric vehicle charging equipment. The AC charging station is connected to the mains, the electric vehicle will be safely and reliably charged by the charging gun interface; to avoid afffecting the product performance, should no acid and alkali and other corrosive gases in the surrounding; try to avoid direct rain or use in environments with high humidity, and should try to prevent damage from impacting the housing.

#### Product parameter description:

rioduct parameter description.			
Model	M7	M11	M22
Input / Output Voltage	AC 230V / Single	AC 400V / Three	AC 400V / Three
	Phase	Phase	Phase
IINDIII / CIIINIII CIIRRENI - I	8,12,16,20,24,28,32	8,10,12,14,16A	8,12,16,20,24,28,32A
	adjustable	adjustable	adjustable
Max Output Power	7.36 KW	11.04 KW	22.08 KW
Frequency	50/60Hz		
Input Cable	1M, hard-wired		
Charging Plug	Type 2(Mennekes)		
Output Cable	5M		
Withstand Voltage	3000V		
Work Altitude	<2000M		
Stand by	<3W		
Protection	over voltage protection, over load protection, over-temp protection, under voltage protection, earth leakage protection,		
	lightning protection, short circuit protection		
IP level	IP65		
Touch Button	No		
LCD Screen	No		
Current Adjustment	Yes		
Bluetooth APP Charging	Yes / No		
WiFi APP charging	Yes / No		
RFID	Yes		
Timing / Appointment	Yes / No		
Certification	CE, RoHS		

#### Function introduction of Type2 Wallbox EV Charger

#### 1.Residual current detection (RCD)

Ac leakage protection automatically detects the AC mismatch between the power supply wires, which indicates that the current flflows through the grounded (PE) wire. Ac residual current fault protection will trip when the current is 30 Ma.

#### 2.Surge protector

In: 3kA, Imax:6kA

#### 3.Leakage protection

When the leakage protection is started, it needs to be cut offff the power outage and restart.

#### 4. Overcurrent protection

When the current exceeds the early warning value, the charging pile cuts offff the power output, restarts automatically after 10 seconds, and does not recover automatically after 3 cycles until you cut of the power and restart.

# 5.Overvoltage protection

The protection starts when the voltage exceeds 275V, and automatically recovers when the voltage is restored and stabilized.

#### 6.Undervoltage protection

Start the protection when the voltage is less than 100V, and restore automatically when the voltage is restored and stabilized.

### 7. Overtemperature protection

Start the protection when the internal temperature of the EV charging station exceeds 85 °C.

#### **Installation Procedure:**

- 1. Please use a percussion drill to drill holes according to the cardboard positioning
- 2. Install expansion bolts(6\*M6\*60MM)
- 3. fix the Mounting backplane with self=tapping screws(6\*M5\*50mm)
- 4. Align the main unit with the buckle on the back panel and install it, and then use screw to fix(4\*M5\*40)

# Instructions

- 1. When the machine is on standby normally, the indicator light is fixed blue.
- 2. Remove the charging gun from the holder, insert the charging gun into the car charging socket.
- 3. After the gun insertion completed, the vehicle automatically starts to charge normally, and the blue meteor light on.
- 4. The indicator light always turns blue after the charge is completed.



# **FUNCTION & PROTECTION**



Over Temperature Protection



Type B Leakage Protection



Waterproof & Dustproof IP65



Ground Protection



Over Voltage Protection



Over Current Protection



Short Circuit Protection



Lightning Protection







# MINKO (SZ) TECHNOLOGY CO., LIMITED



+8613539872669



yumiko@szminko.com



evstationcharger.com